



- 1 = Stop-Mutter M10
- 2 = Schraube M10 x 25
- 3 = Schubarm
- 4 = Ben-Bolzen / KL-Sicherung
- 5 = Motorlaufwagen
- 6 = Schraube M10 x 40
- 7 = Gabelkopf 10 mm
- 8 = T-Eisen 50 x 30 x 5 mm

